

Termex is a new method of insulation, a step away from traditional methods. As a result, the condition and requirements of a site may be different to what could be typically expected. The following information will give you an indication of what needs to be in place and the standard required prior to the arrival of Termex installers on site.



Lofts

What needs to be in place:

- **Parking near to house (ideally no more than 20m away)**
- **3x 240v sockets**
- **Easy access into the loft (notify if not)**
- **Lighting in the loft (notify if not)**
- **Loft to be empty**



Due to the nature of the installation, pipes and cables will be placed through the building. When applying the product with the glue/water mix some dust may be created, but will be contained within the loft area and left to settle over a short period of time.



It is important that these procedures are in place prior to the agreed installation date. Should a site be visited and seen not to be satisfactory for the installation of Termex, process will be delayed until this is not the case. If in doubt please contact us on 01347 821020 before the date installation is due to commence.